


Installation instruction
Montageanleitung
Upute za montažu



The gap between the holes /
Abstand zwischen den Lochern /
Razmak između rupa:

OP61VL x=520 mm
OP76VL x=672 mm